

Protokoll: Fertiger 1

Rezept: Gruyere 8
Datum: 23.05.2017
Zeit: 08:17:14

Zeit	Logeintrag	Zeit Soll [min]	Zeit Ist Step	Rührwerk [UPM]	Bruchpumpe [%]	Temp. Soll [°C]	Temp. Ist [°C]
08:17:14	Start Protokoll						
08:17:15	Schritt 1	160.0	00:04:09	3.5	0	0.0	20.1
08:17:15	03: Rühren						
08:21:24	Schritt 2	5.0	00:04:59	4.8	0	19.7	19.7
08:21:24	05: Heizen und rühren						
08:26:23	Schritt 3	5.0	00:05:00	4.8	0	21.6	21.6
08:26:23	05: Heizen und rühren						
08:31:23	Schritt 4	5.0	00:05:00	5.2	0	22.4	22.4
08:31:23	05: Heizen und rühren						
08:36:23	Schritt 5	5.0	00:05:19	5.2	0	25.0	25.0
08:36:23	05: Heizen und rühren						
08:36:23	Bedieneranforderung aktiv						
08:41:42	Schritt 6	29.0	00:30:15	6.1	50	28.6	28.6
08:41:42	05: Heizen und rühren						
09:11:57	Schritt 7	3.0	00:03:01	5.6	0	0.0	30.4
09:11:57	03: Rühren						
09:14:58	Schritt 8	1.0	00:41:31	2.6	0	0.0	30.5
09:14:58	03: Rühren						
09:14:58	Bedieneranforderung bestätigt						
09:14:59	Schritt 9	32.0	00:00:01	0.0	43	0.0	30.5
09:14:59	00: Keine Funktion, warten						
09:14:59	Bedieneranforderung aktiv						
09:56:30	Schritt 10	1.0	00:00:32	2.1	0	0.0	31.0
09:56:30	04: Schneiden						
09:56:30	Bedieneranforderung bestätigt						
09:57:02	Schritt 11	1.0	00:00:25	3.5	0	0.0	30.9
09:57:02	04: Schneiden						
09:57:27	Schritt 12	1.0	00:00:32	4.3	0	0.0	31.0
09:57:27	04: Schneiden						
09:57:59	Schritt 13	1.0	00:00:15	5.2	0	0.0	31.0
09:57:59	04: Schneiden						
09:58:14	Schritt 14	1.0	00:00:15	6.1	0	0.0	31.0
09:58:14	04: Schneiden						
09:58:29	Schritt 15	0.5	00:00:23	6.5	0	0.0	30.9
09:58:29	04: Schneiden						
09:58:52	Schritt 16	0.5	00:00:22	7.0	0	0.0	30.9
09:58:52	04: Schneiden						
09:59:14	Schritt 17	0.5	00:00:10	7.4	0	0.0	30.9
09:59:14	04: Schneiden						
09:59:24	Schritt 18	5.0	00:04:56	8.3	0	0.0	30.9
09:59:24	04: Schneiden						
09:59:24	Bedieneranforderung aktiv						
10:04:20	Schritt 19	5.0	00:00:42	0.0	0	0.0	30.8
10:04:20	00: Keine Funktion, warten						
10:04:20	Bedieneranforderung bestätigt						
10:05:02	Schritt 20	5.0	00:05:00	6.1	0	0.0	30.8
10:05:02	03: Rühren						
10:10:02	Schritt 21	20.0	00:20:00	6.1	0	30.7	30.7
10:10:02	05: Heizen und rühren						
10:30:02	Schritt 22	20.0	00:23:14	6.1	0	39.1	39.1
10:30:02	05: Heizen und rühren						
10:30:02	Bedieneranforderung aktiv						
10:53:16	Schritt 23	8.0	00:03:11	6.1	0	0.0	57.4
10:53:16	03: Rühren						
10:56:27	Schritt 24	0.2	00:00:11	6.5	0	0.0	57.4
10:56:27	10: Bruchentleeren mit rühren						
10:56:27	Bedieneranforderung bestätigt						

[Hier könnte ihr
Logo stehen!]

10:56:38	Schritt 25	1.0	00:01:00	6.5	90	0.0	57.4
10:56:38	10: Bruchentleeren mit rühren						
10:57:38	Schritt 26	1.0	00:01:00	6.5	75	0.0	57.4
10:57:38	10: Bruchentleeren mit rühren						
10:58:38	Schritt 27	1.0	00:01:00	5.2	65	0.0	57.4
10:58:38	10: Bruchentleeren mit rühren						
10:59:38	Schritt 28	1.0	00:01:00	4.3	65	0.0	57.4
10:59:38	10: Bruchentleeren mit rühren						
11:00:38	Schritt 29	2.0	00:01:03	4.3	60	0.0	57.3
11:00:38	10: Bruchentleeren mit rühren						
11:01:41	Schritt 30	10.0		0.0	85	0.0	57.1
11:01:41	10: Bruchentleeren mit rühren						
11:01:58	Bruchwaschwasser Ein						
11:02:52	Angehalten Start						
11:02:52	Angehalten Ende						
11:02:54	Bruchwaschwasser Aus						
11:02:56	Ende Protokoll						